

# Vertical Installation Instructions

**WARNING – CURTAIN & BLIND CORDS HAVE CAUSED THE DEATH OF YOUNG CHILDREN AND MUST BE INSTALLED SO THAT THEY ARE NOT A STRANGULATION HAZARD. FOLLOW THE INSTALLATION INSTRUCTIONS**

1. Install Ceiling Fix Brackets or Face Fit Brackets where required using appropriate screws for the application. Ensure the brackets are approximately 100mm in from each end and the spacings are no greater than 900mm.
2. Centre the track in the window and hook the front edge of the track, (inside front for slimline), on to the brackets.
3. Push the back of the track upwards until the track clips solidly in place. Pull down on the track carefully to check that it is secure.
4. Hang the fabric slats in sequence, making sure all hems face the same way.
5. Install a cord safety device as per the instructions provided with the device.

All corded devices to be in compliance with the following as per the Trade Practice (Consumer Product Safety Standard-Corded Internal Window Coverings) Regulations 2010 (2010 no.212.)

# Cord Safe (Including Screw)

Part No. 5.6000..

**WARNING – CURTAIN & BLIND CORDS HAVE CAUSED THE DEATH OF YOUNG CHILDREN AND MUST BE INSTALLED SO THAT THEY ARE NOT A STRANGULATION HAZARD. FOLLOW THE INSTALLATION INSTRUCTIONS**

